

RTSP URL for LaView IP Camera

URL

rtsp://IP:RTSPPort/Streaming/Channes/ID/?transportmode=unicast

Explanation

ID means main stream or sub stream and channel number. If the ID is 102, we will get **sub stream** of the 1st channel. If the ID is 101, we will get main stream.

RTSP URL supports to add username and password:

rtsp://admin:12345@IP:Port/Streaming/Channels/ID/?transportmode=multicast.

The type of authorization supports BASIC and DIGEST.

You can disable RTSP authentication from web interface of IP camera

Examples

- Get sub stream from IP camera
rtsp://172.28.1.52:554/Streaming/Channels/102/?transportmode=unicast
- Get 1st IP camera from a hybrid DVR
rtsp://172.28.1.70:554/Streaming/Channels/1701/?transportmode=unicast
- Get channel 0 from DVR
rtsp://admin:12345@172.28.1.70/Streaming/channels/001/?transportmode=unicast