Step 5. Configure start up wizard

Select the screen resolution from the drop-down menu based on your TV/monitor's resolution.



Check this box if you wish to see this wizard again after you reboot your system.



We strongly recommend that you change the default Admin password '12345' for better security protection.

Select the applicable time zone, date/time format, and time.

We recommend checking 'Enable DHCP' even if your DVR is not connected to the internet, this will automatically get the DVR IP address.



The wizard will show additional network information, click 'Next' to proceed.



To initialize the hard drive click the 'Init' box otherwise the DVR will NOT record.



click 'Next' to proceed.



Choose continuous or motion detection recording from the listed options. Check the 'Start Recording' box to initialize recording. Click 'Ok' to finish the wizard.



What is in the box?

- HD-TVI Digital Video Recorder
- HD-TVI Analog Cameras
- Siamese BNC Cables
- 1-4,8 Camera Power Splitter
- Mouse
- Remote Control
- DVR Power Adapter
- Camera Power Adapter
- Quick Start Guide
- Warranty Card
- Security Stickers



1 Power LED	Indicates if the DVR is powered on	7 VGA Port	Connects to TV or computer monitor
2 Status LED	Indicates if the Hard Drive is working	8 Audio I/O	Connects an extra microphone/speaker (not included)
3 Tx/Rx LED	Indicates if the Network is active	9 LAN	Connects to your router
4 Video In	Connects cameras via BNC cables	10 RS-485	Connection for additional PTZ camera (not Included)
5 USB Port	Connects to a USB mouse or flash drive	11 12V	Connects the12V DC Power Supply
6 HDMI Port	Connects to HDTV or computer monitor	12 Power	Power Switch

Troubleshooting

Problem	Solution
No display/No signal/Invalid format	• Make sure the VGA/HDMI cable is properly connected to both the DVR and TV/monitor *NOTE: A laptop cannot be used as a screen* • Make sure your TV/monitor is on the correct video input (e.g. HDMI1, HDMI2, etc.) • Try switching to another 1080p TV/monitor and adjust the output resolution in the DVR menu • On the front of the DVR check that the power LED light is on
No picture/No video	• Make sure the camera is completely connected to the power splitters well as the Video In plug
Cannot log in	• The default user name is: ***admin*** and the default password is: ***12345***. If you don't remember your old password, please submit a ticket to us at www.laviewusa.com/contact/.
Camera picture is not clear	• Make sure the camera is not placed behind a window, there is no interference or a strong light source in front of the camera • In DVR Menu>Record>Parameter>Resolution, set the sub stream resolution to CIF for all channels • Move the camera to a different location and/or direction *NOTE: The live view (sub stream) resolution is NOT the actual image quality recorded (Main stream); Connection of excessive length (over 200ft) of BNC cable will drop the camera image quality; Working at extreme weather condition (below -40F or above 140F) will drop the image quality and damage the camera.*
Night vision is not working	• The infrared activates automatically when the environment is dark enough. You can check that the camera infrared bulbs are working properly as they turn light red in dark environments
DVR is not recording	• Check that the hard drive status is normal and is initialized under the Main Menu>HDD>General • Enable the record mode (Normal or Motion Detection) under the Main Menu>Record>Schedule>Edit for the selected camera

LaView
Innovation That Secures

HD-TVI QUICK START GUIDE

Remote Viewing

View footage on your mobile devices with our app. You can either scan the provided QR code or search LaView Net in the app store.

LaView NET

Download on the App Store

ANDROID APP ON Google play

SCAN ME

Content may vary by model, including the number of channels, cameras, configuration, and hard drive capacity.

Questions?

Call us at: 626-898-4988 (M-F from 9am to 6pm PST)
Open support ticket at: www.laviewusa.com/contact
Tutorial videos & user manual at: www.laviewusa.com/support

Copyright © LaView Eagle-Eye Technology Inc. 2015

www.laviewusa.com

QUICK START GUIDE

We recommend testing all the cameras and cables prior to installation.



Step 1. Connect your cameras

- Connect the BNC plug and power plug of the siamese cable into the camera
- Connect the opposite BNC plug into the DVR VIDEO IN port and the power plug into the camera power splitter (Repeat for all cameras)
- Connect the power splitter into camera power supply

Step 2. Connect to your monitor/TV

- Connect your DVR and TV/monitor with a HDMI or VGA cable (Not included)

Note: Your monitor/TV must support the output resolution of the DVR or you may get a black screen or a possible error message. You cannot use a laptop as a display.

Step 3. Connect the mouse and power

- Connect the mouse to the USB port
- Connect the 12V DVR power adapter to the DVR

Step 4. Connect to your network (OPTIONAL)

- Connect the LAN port on the DVR to the LAN port on your router via an Ethernet cable for remote viewing on your mobile phone, tablets, PC and Mac

Note: The DVR will still work as a standalone video recorder if you do not have internet connection and skip this step.

Step 5. Configure the start up wizard

- The connection is now completed. Turn on the power switch and follow the start-up wizard on your screen to confirgure the DVR. (next page)